



GTEN Infinite v5 Series

LTE Modem Router

Change (SSID) Network Name

Please follow the Infinite Tablet Modem/Router login steps below:

1. Connect to the Network (2.4G, or 5G SSID) with the router (Default SSID is displayed on the sticker at the bottom of the router).
2. Enter the default Wifi password (The default WIFI password (WIFI key) is displayed on the sticker at the bottom of the router).
3. Make sure you are connected to the correct network (SSID). Pull up a web browser, e.g., Google Chrome, Firefox, Safari, Edge, or Explorer.
4. In the URL address bar (web address), type in 192.168.2.1, and press **Enter**, or "Return", on your keyboard. ***It is not necessary to enter "http://"**
5. You should be at the login page for the router settings. The default **username** and **password** for the router settings login is (in all lower case, for both):
admin
6. At the router's main page, on the left, under **Advanced Settings**, click on **Wireless 2.4GHz** link.
7. Find **SSID**, within the Wireless 2.4GHz **General** tab; delete the existing SSID (Network name), and enter the new SSID.
8. Once you have entered the new SSID, click **Apply** at the bottom of the page to save the new settings.
 - a. *Once you click **Apply**, devices will be disconnected from the network. All devices will need to reconnect with the new SSID (network name)*
9. For 5GHz SSID, repeat steps **#6 ~ #8**, using the **Wireless 5GHz** link.

